

## Removal Steps:

- 1) Diver team 1 secure Clump with hard rigging (Chain) and handling ropes then return to pier.
- 2) Diver team 2 Attach and inflate buoyancy bladders to break bottom suction and attain neutral buoyancy.
- 3) Shore team manually handles lines to move tire clump to as close to shoreline as possible.
- 4) Tires are moved to water line by dive teams and disposal dumpster individually by shore team.
- 5) Repeat steps as time allows for additional tire clumps.

